

Give Fifth Wheel Snags the Hook

Reaching to grab latch handle can cause a shoulder injury.



Use a pin puller to reach and hook latch handle.

Unlocking a fifth wheel to release a trailer kingpin can be agonizing. Bending and reaching under the trailer to wrestle a stubborn release latch can cause neck, shoulder and back injury. Grease, oil, and road grime can mess up your work clothes too. Using a pin puller is a simple and safe way to hook and pull a release latch without having to reach under the trailer.



TIPS TO LIVE BY

- Align the truck and trailer on firm, level ground and set the trailer parking brakes.
- Pull forward slightly to release tension on the fifth wheel release latch.
- Do not exhaust air from tractor suspension before uncoupling.
- Stand parallel to the trailer and use the pin puller to reach, hook, and pull the fifth wheel release latch.
- Report mechanical problems to your supervisor or repair shop.
- □ Wear reflective clothing when outside your truck.
- Before you exit the cab look for debris, ice, oil or holes in the ground.
- Always use 3 points of contact to enter or exit your cab.



TIRES is a project of the Safety & Health Assessment & Research for Prevention (SHARP) program of the Washington State Department of Labor & Industries. TIRES is supported in part by CDC/NIOSH grant# U60 OH008487. For more information and free training resources visit

SHARP Report No.: 90-70-2019